


Instruction Manual




PARTS LIST

A x 1



B x 1



C x 1




D x 2




E x 5




F x 3




G x 2




H x 2




I x 2




J x 5



K x 1




L x 9



M (M6x10) x 4




N (M6x35) x 14




O (M6x40) x 20




P (M6x47) x 25



Q






ASSEMBLY OVERVIEW




Step 1



Pay attention to the position and direction of components , especially screw holes



Step 2






Do not over-tighten the bolts/screws





Step 3

Pay attention to the holes at Part E ,
refer to Step 11 and 12




Step 4




Refer to Step 5 ,
ensure correct installation .






Step 5





Step 6



Step 7







Step 8






Step 9

Refer to three views and Step 11, pay attention to holes of Part F and ensure correct installation





O x 3




Step 10




Step 11-(1)




Step 11-(2)







Step 12



Repeat the method of Step 11 to install other Part J .





Step 13



M x 4

Step 14



N x 6

ASSEMBLE ACCOMPLISHED

